UNIVERSAL HOSE HANGER

PART #90992SS



Call: (413)532-4030 Visit: www.ruwac.com Email: info@ruwac.com

HOSE HANGER LOCATIONS FOR RED LINE SERIES:

- USE THE PROVIDED HARDWARE IN THE BAG LABELED FOR YOUR VACUUM SHOWN BELOW, SOME DRILLING MAY BE REQUIRED.
- LOCATIONS SHOWN ARE APPROXIMATE, USE YOUR HOSE HANGER FOR A HOLE TEMPLATE.
- ENSURE THAT YOU HAVE ENOUGH HEIGHT TO COIL YOUR HOSE, OR YOU MAY ELECT TO MOUNT YOUR HOSE HANGER IN A STATIONARY LOCATION (I.E. WALL MOUNT).



NOTE THAT FOR **#90992SKIT03** YOU MAY BE REQ'D TO DRILL/TAP THE FRAME FOR A M8 HEX BOLT. NEWER FRAMES COME PREDRILLED.



HOSE HANGER LOCATIONS FOR WORKHORSE AND POWERHOUSE SERIES:

- USE THE PROVIDED HARDWARE IN THE BAG LABELED FOR YOUR VACUUM SHOWN BELOW, SOME DRILLING MAY BE REQUIRED.
- LOCATIONS SHOWN ARE APPROXIMATE, USE YOUR HOSE HANGER FOR A HOLE TEMPLATE.
- ENSURE THAT YOU HAVE ENOUGH HEIGHT TO COIL YOUR HOSE, OR YOU MAY ELECT TO MOUNT YOUR HOSE HANGER IN A STATIONARY LOCATION (I.E. WALL MOUNT).
- ON EXPLOSION PROOF CERTIFIED UNITS THE HOSE HANGER MUST BE GROUNDED, PER UL
 1203 STANDARDS. WE HAVE INCLUDED THE NECESSARY HARDWARE/WIRES. IT IS YOUR
 RESPONSIBILITY TO CONFIRM GROUNDING (HOSE HANGER TO LINE GROUND OR GROUNDING
 REEL) USING A STANDARD OHMMETER. CALL RUWAC CUSTOMER SUPPORT (413) 532-4030
 WITH YOUR VACUUM SERIAL NUMBER READY IF YOU HAVE ANY QUESTIONS. SEE LAST PAGE
 FOR SAMPLE GROUNDING INSTRUCTIONS.



NOTE THAT FOR **#90992SSKIT03** YOU MAY BE REQ'D TO DRILL/TAP THE FRAME FOR A M8 HEX BOLT. NEWER FRAMES COME PREDRILLED.



HOSE HANGER LOCATIONS FOR MX300 AND MX360 SERIES:

- USE THE PROVIDED HARDWARE IN THE BAG LABELED FOR YOUR VACUUM SHOWN BELOW, SOME DRILLING MAY BE REQUIRED.
- LOCATIONS SHOWN ARE APPROXIMATE, USE YOUR HOSE HANGER FOR A HOLE TEMPLATE.
- ENSURE THAT YOU HAVE ENOUGH HEIGHT TO COIL YOUR HOSE, OR YOU MAY ELECT TO MOUNT YOUR HOSE HANGER IN A STATIONARY LOCATION (I.E. WALL MOUNT).
- ON EXPLOSION PROOF CERTIFIED UNITS THE HOSE HANGER MUST BE GROUNDED, PER UL 1203 STANDARDS. WE HAVE INCLUDED THE NECESSARY HARDWARE/WIRES. IT IS YOUR RESPONSIBILITY TO CONFIRM GROUNDING (HOSE HANGER TO LINE GROUND OR GROUNDING REEL) USING A STANDARD OHMMETER. CALL RUWAC CUSTOMER SUPPORT (413) 532-4030 WITH YOUR VACUUM SERIAL NUMBER READY IF YOU HAVE ANY QUESTIONS. SEE LAST PAGE FOR SAMPLE GROUNDING INSTRUCTIONS.



NOTE THAT FOR **#90992SSKIT03** YOU MAY BE REQ'D TO DRILL/TAP THE FRAME FOR A M8 HEX BOLT. NEWER FRAMES COME PREDRILLED.

