#884023



Discharge Settling Chamber for MX360 Series:

Mounts directly to the discharge of any MX360 Series Vacuum. Allows the material to settle out of the liquid bath when the machine is not in use. Visual siteglass enables the operator to see when full.





*Shown with MX361EX - Industry Leading Immersion Separation Vacuum System

Call: (413)532-4030



- Stainless steel construction, inline sight glass for water level detection and sanitary clamps and cap for secure closure
- Allows MX360 Series Vacuums to run with the ball valve open
- Once the vacuum is turned off, any heavy metal dust will accumulate in the see-through settling chamber
- Once full, the metal dust will displace the water and the ball valve can be closed to empty
- The unit should still be checked for build-up, as there will be some metal powders that do not travel out the discharge